



HEARTBEAT FITNESS REPAIR

SERVICE • REPAIR • PREVENTIVE MAINTENANCE

Factory-trained service for residential and commercial fitness equipment

(727) 512-5120 • service@theequipmentfixer.com • TheEquipmentFixer.com

MFG MAINTENANCE REFERENCE

REF: HFR-MFG-PRECOR-2026

PAGE 1 OF 2

CARING FOR YOUR PRECOR EQUIPMENT

An Independent Heartbeat Fitness Repair Maintenance Reference

Independent maintenance reference prepared by Heartbeat Fitness Repair from publicly available Precor guidance • Not affiliated with, sponsored by, or endorsed by Precor. All product and brand names are trademarks of their respective owners.

1. EQUIPMENT WE SERVICE

Precor is a commercial-club staple, with the AMT and EFX lines' ramp-based motion as its most distinctive (and highest-maintenance) mechanism.

TREADMILLS

Slat-belt TRM 500/600/700/800
with Ground Effects cushioning

EFX & AMT

EFX 500/600/800, AMT 800 (Open
Stride)

BIKES & CLIMBERS

Stages SC2/SC3 cycles, SCL 800
stairclimber

STRENGTH

Resolute™, Vitality™, Discovery™,
Dual Adjustable Pulley

2. STEP-BY-STEP: EFX/AMT RAMP & ROLLER CARE

STEP 1: DAILY WIPE

Wipe the ramp with a soft cloth
whenever visibly soiled.

STEP 2: ROTATE ROLLERS

Rotate roller wheels to expose and
clean all contact surfaces.

STEP 3: AVOID ACIDIC CLEANERS

Use only manufacturer-approved
cleaners — acidic products
degrade the ramp coating.

STEP 4: BI-MONTHLY TENSION CHECK

Check treadmill belt
alignment/tension at the rear hex
bolts — never lubricate a Precor
belt.

3. MANUFACTURER-RECOMMENDED MAINTENANCE

COMPONENT	PRECOR GUIDANCE	INTERVAL
Treadmill Belt	Designed to run without added lubrication — do NOT lubricate. Maintenance is alignment/tension only, via rear hex-bolt quarter-turns.	Bi-monthly alignment/tension check
EFX/AMT Ramp & Rollers	Low-friction ramp coating should be kept clean, not lubricated. Wipe ramp and rotate roller wheels to reach all contact surfaces; avoid acidic cleaners that degrade the coating.	Daily or whenever visibly soiled
Strength Guide Rods	Silicone spray only — never petroleum-based oil, which attracts dirt and hair to weight plates. Inspect cable terminations, jam nuts, and pulley wheels weekly.	Weekly
General Inspection	Roller/bearing and electrical inspection.	Annually

PRO TIP: NEVER LUBRICATE A PRECOR TREADMILL BELT

- Unlike most home-treadmill brands, Precor belts are engineered to run dry. Applying silicone lubricant here — the standard fix everywhere else — can actually cause slipping and tracking problems on Precor decks.



HEARTBEAT FITNESS REPAIR

SERVICE • REPAIR • PREVENTIVE MAINTENANCE

Factory-trained service for residential and commercial fitness equipment

(727) 512-5120 • service@theequipmentfixer.com • TheEquipmentFixer.com

MFG MAINTENANCE REFERENCE

REF: HFR-MFG-PRECOR-2026

PAGE 2 OF 2

CARING FOR YOUR PRECOR EQUIPMENT

Independent maintenance reference prepared by Heartbeat Fitness Repair from publicly available Precor guidance • Not affiliated with, sponsored by, or endorsed by Precor. All product and brand names are trademarks of their respective owners.

4. COMMON PRECOR FAILURE POINTS

OBSERVED SYMPTOM	LIKELY CAUSE	RISK IF IGNORED	RECOMMENDED ACTION
EFX/AMT Ramp Binding or Noise	Ramp roller wear, or (on ramp-motorized units) low backup-battery voltage causing ramp faults.	Rough or locked motion mid-workout.	Check ramp rollers and backup battery voltage before replacing the ramp motor.
Incline/Lift Motor Fault (40-series codes)	Potentiometer fault or lift motor failure.	Unit locks out incline function.	Diagnose the potentiometer before replacing the motor.
Console / PCA Board Failure	Circuit board or touchscreen fault (P80/P82/P62 consoles) — the top cited “unit down” cause across Precor cardio lines.	Unit unusable until repaired.	Isolate to the PCA board specifically before a full console swap.
Functional Trainer Cable Wear	Standard cable fraying from cycling under load.	Sudden failure under load.	Inspect weekly per the published cable/guide-rod schedule.

5. WHAT OUR TECHNICIANS CHECK ON EVERY PRECOR VISIT

RAMP & ROLLER SYSTEM

EFX/AMT ramp cleanliness and roller wear — never lubricated

CONSOLE / PCA BOARD

Isolated diagnostics before a full console replacement

STRENGTH CABLES & GUIDE RODS

Silicone-only lubrication per Precor spec

OWN ONE OF THESE MACHINES? WE SERVICE THEM RIGHT.

Heartbeat Fitness Repair's technicians are factory-trained across major fitness equipment brands, including Precor, and carry the diagnostic tools and OEM-spec parts knowledge to service it correctly the first time.

PHONE

(727) 512-5120

EMAIL

service@theequipmentfixer.com

WEB

TheEquipmentFixer.com