



HEARTBEAT FITNESS REPAIR

SERVICE • REPAIR • PREVENTIVE MAINTENANCE

Factory-trained service for residential and commercial fitness equipment

(727) 512-5120 • service@theequipmentfixer.com • TheEquipmentFixer.com

MFG MAINTENANCE REFERENCE

REF: HFR-MFG-PROFORM-2026

PAGE 1 OF 2

CARING FOR YOUR PROFORM EQUIPMENT

An Independent Heartbeat Fitness Repair Maintenance Reference

Independent maintenance reference prepared by Heartbeat Fitness Repair from publicly available ProForm guidance • Not affiliated with, sponsored by, or endorsed by ProForm. All product and brand names are trademarks of their respective owners.

1. EQUIPMENT WE SERVICE

ProForm shares its iFIT platform and engineering with NordicTrack, and shows up constantly in home and condo fitness rooms across Tampa Bay.

TREADMILLS

Carbon TL/TLS/TLX, Carbon Pro 2000/9000, Sport series

ELLIPTICALS

Carbon EL, Sport series ellipticals

BIKES

Carbon Pro Studio Bike (Pro10), Carbon CX indoor cycle

ROWERS

Carbon Pro10 rower

2. STEP-BY-STEP: THE PROFORM BELT SERVICE PROCEDURE

STEP 1: MONTHLY VISUAL CHECK

Inspect the belt for fraying, tearing, or seam separation; check under the motor hood for rubber residue.

STEP 2: LOOSEN & LUBRICATE

Loosen belt tension and apply lubricant under the deck per the standard procedure.

STEP 3: NEVER SURFACE-SPRAY

Apply lubricant only under the deck — never sprayed directly onto the exposed belt.

STEP 4: RETEST TENSION

Re-tighten the belt and retest for smooth, centered tracking.

3. MANUFACTURER-RECOMMENDED MAINTENANCE

COMPONENT	PROFORM GUIDANCE	INTERVAL
Walking Belt Inspection	Visually check for fraying, tearing, seam separation, or misalignment. Check under the motor hood for black rubber residue, a sign of friction or misalignment.	Monthly
Walking Belt Lubrication	Apply lubricant under the deck per the standard procedure — never spray it directly onto the exposed belt surface as a “quick fix.”	At least annually; more often under heavy use
Elliptical Care	Lubricate pivot/moving joints per the model manual; wipe sweat contact points after use; dust regularly.	Full bolt/fastener inspection every 3–6 months
Console & Vents	Clean with a cloth dampened in mild cleaner, never sprayed directly on the console; vacuum vent/fan covers to prevent overheating.	Ongoing, per usage

PRO TIP: WHEN IN DOUBT, DON'T GUESS THE LUBRICANT

- ProForm sells its own matched Treadmill Maintenance Kit rather than leaving lubricant choice to guesswork — a sign they don't want generic products used. We stock OEM-equivalent 100% silicone lubricant for exactly this reason.



HEARTBEAT FITNESS REPAIR

SERVICE • REPAIR • PREVENTIVE MAINTENANCE

Factory-trained service for residential and commercial fitness equipment

(727) 512-5120 • service@theequipmentfixer.com • TheEquipmentFixer.com

MFG MAINTENANCE REFERENCE

REF: HFR-MFG-PROFORM-2026

PAGE 2 OF 2

CARING FOR YOUR PROFORM EQUIPMENT

Independent maintenance reference prepared by Heartbeat Fitness Repair from publicly available ProForm guidance • Not affiliated with, sponsored by, or endorsed by ProForm. All product and brand names are trademarks of their respective owners.

4. COMMON PROFORM FAILURE POINTS

OBSERVED SYMPTOM	LIKELY CAUSE	RISK IF IGNORED	RECOMMENDED ACTION
Touchscreen Frozen or Unresponsive	iFIT software fault or lost Wi-Fi connection.	No functional workout tracking, but not a safety issue.	Firmware update or factory reset via Settings > Wireless Network Mode before assuming hardware failure.
Incline Won't Respond	Calibration fault; repeated failure suggests a failing incline motor.	Uneven deck angle mid-workout is a fall hazard.	Run the console's incline calibration menu or button-combo reset first.
Belt Squeaking or Jerky Motion	Misalignment (squeak) or over-tightening (jerky motion).	Accelerated belt and roller wear.	Adjust tension at the hex-key idler roller screws — never spray lubricant directly on the belt as a shortcut.
Treadmill Powers Off Mid-Session	Wiring/sensor fault, motor control board issue, or a burning smell.	Sudden shutdown mid-workout is a fall hazard; electrical fault risk.	Stop use immediately and schedule a certified inspection — this is treated as non-DIY by the manufacturer.

5. WHAT OUR TECHNICIANS CHECK ON EVERY PROFORM VISIT

BELT & DECK CONDITION

Monthly-grade fraying, tracking, and friction-residue inspection

INCLINE CALIBRATION

Full recalibration rather than a surface-level reset

ELECTRICAL & WIRING

Amp draw, connections, and surge protection review

OWN ONE OF THESE MACHINES? WE SERVICE THEM RIGHT.

Heartbeat Fitness Repair's technicians are factory-trained across major fitness equipment brands, including ProForm, and carry the diagnostic tools and OEM-spec parts knowledge to service it correctly the first time.

PHONE

(727) 512-5120

EMAIL

service@theequipmentfixer.com

WEB

TheEquipmentFixer.com